



## J/105 Rig Tension Chart

Using a PS 10 Loos Red Gauge

### Standard (Old-Style) Turnbuckles

Wind Strength in Knots:	0-7	8-16	17+
Upper Shrouds			
Adjustment (turns)		+1.5	+2
Loos Gauge	37	41	51
Intermediates			
Adjustment (turns)		+.75	+.75
Loos Gauge	12	17	22
Lower Shrouds			
Adjustment (turns)		+.5	+.5
Loos Gauge	0	0	5
0-7 knots is the 'Base' setting; adjust tighter for more wind			

### New Turnbuckles

Wind Strength in Knots:	0-7	8-16	17+
Upper Shrouds			
Adjustment (turns)		+3	+4
Loos Gauge	37	41	51
Intermediates			
Adjustment (turns)		+1.5	+1.5
Loos Gauge	12	17	22
Lower Shrouds			
Adjustment (turns)		+1	+1
Loos Gauge	0	0	5
0-7 knots is the 'Base' setting; adjust tighter for more wind			